

TiVo® Premiere Q and Preview



Start Here ▶▶

Follow these easy steps to connect your TiVo Premiere Q or Preview

Welcome! Start Here ▶▶

Setting up your TiVo® Premiere Q and Preview is easy.

Questions Call DRN's Technical Assistance Group (701) 344-5005

The TiVo Service is what makes your Premiere smart. It includes everything from your program listings to Season Pass® recordings and WishList® searches—all the cool features you've heard about.

To get started connecting your TiVo Premiere Q or Preview, go to step 1, below.

Connecting Your TiVo Premiere Q or Preview

6


Tune your TV to see the Welcome Screen

Turn on your TV.

If you don't see the Welcome screen:

Use the Input, Source, or TV/Video button on your TV remote or TV to select the audio/video input source you used in step 4. On many TVs, you can also change the channel to select different input sources.

When you see the Welcome screen, you're ready to begin Guided Setup. To complete Guided Setup, just follow the on-screen instructions.



Call DRN to Activate Service

877-559-4694 or 701-344-5005

Monday - Friday
8am - 5pm

1

Get to know your cables

Cables Provided

Ethernet cable for connecting to the TiVo Service through a wired network.



HDMI cable for high definition video and digital audio - **recommended for HD**



Power cord

Connect to Your Cable Service

Connect the Coaxial RF cable coming from the wall to the CABLE IN jack on the back of the Premiere.

If this cable is connected to your TV, disconnect it and connect it to the TiVo Premiere instead.

5

Plug in the Power Cord

The TiVo Premiere's front panel displays a green light at startup.


4

3

Connect to the TiVo® Service: Network

The TiVo Premiere needs to connect to the TiVo Service to receive program listings, service updates, and other information. Network-connected Premieres also have access to video downloads, podcasts, and other cool features.

You can connect to the TiVo Service through a wireless N, wireless G, or wired home network. Choose how your Premiere Q will connect:



Wireless G or N - Connect a TiVo Wireless G or N USB Network Adaptor (**sold separately**) to one of the Premiere's USB ports, and follow the on-screen instructions. The TiVo® Wireless G or N USB Network Adaptor is available from Dickey Rural Networks

Wired (Ethernet) - Connect an Ethernet jack from your home network to the TiVo Premiere's Ethernet jack (the upper jack pictured at left).

*Wireless G USB Network Adaptor

Connect Audio/Video

Connect your video and audio cables between your television and your TiVo Premiere.

If your high-definition TV has an HDMI port (Recommended):

Connect the HDMI cable from the TiVo Premiere's HDMI OUT jack to the HDMI IN port on the back of your high-definition TV, as shown above. If you use this method, video and audio are connected with this one cable! You can move to Step 4.

If your high-definition TV does not have an HDMI port:


A. Connect video: Connect a Component Video cable (green, blue, red) (**may have come with your TV, or sold separately**) from the TiVo Premiere Q's COMPONENT OUT jack to the COMPONENT IN jack on the back of your high-definition TV.

B. Connect audio: Connect the red and white ends of a Composite A/V cable from the TiVo Premiere's A/V OUT jacks to the A/V IN jacks on your TV. Do not connect the yellow end (standard video).

Note: Most TVs have more than one input. Make note of the input you use for video, and use the same input when you connect audio.

If you have a standard-definition TV:

For a standard definition (non-HD) video connection, connect all ends of the included Composite cables (red, white, and yellow) from the A/V OUT jacks on the TiVo Premiere to the red, white, and yellow A/V IN jacks on your TV.



Need some help?

(701)-344-5005 Call DRN 877-559-4694